# **Green Plan**

# \*All Commands Prompt unless specified Powershell will not be used\*

# 1. Check Physical Stuff

- a. Check for tape under the mouse
- b. Suspicious things connected to the computer
- c. USB
- d. ETC.
- e. Don't open the box
- f. Check For IOT Devices/Phones

# 2. Users

- a. Local users
  - i. Change passwords. Don't change passwords with command line
  - ii. Disable unnecessary users but don't delete
    - 1. "net user <username> /active:no"
- b. Domain Users
  - i. Create Domain Admin accounts for each windows server admin
  - ii. Find out, total users. Look in all OUs for hidden users. Services Accounts that aren't service accounts.
  - iii. Change passwords for scored users.
  - iv. Disable unnecessary users but don't delete

#### 3. Firewall

- a. Enable firewall service
  - i. Windows firewall (Advanced Security)
    - 1. Right-click top level and turn all profiles on.
  - ii. Commands
    - 1. Enable and start
      - a. Sc config mpsvc start=auto
      - b. Net start mpsvc /y
    - Enable logging
      - a. Netsh advfirewall set allprofiles loggin droppedconnections enable
  - iii. Netsh advfirewall set allprofiles settings remotemanagment disable

#### Windows Defender Firewall -

- 1. Ensure Windows Defender Firewall is on.
- 2. Restore Default Policy: Right-click "Windows Firewall w/ Advanced Security on Local Computer" and select "Restore Default Policy".
- 3. Disable every Inbound rule except:
  - a. Allow Core Networking ICMPv4 in
  - b. Allow Core Networking DHCP (Dynamic Host Config Protocol) in

- c. ADD Allow Port UDP 1514 in (Local Subnet Only: Right-click rule  $\rightarrow$  Scope  $\rightarrow$  Add Local IP)
- 4. Disable every Outbound rule except:
  - a. Internet Explorer, TCP 80,443 | UDP 53
  - b. ADD Allow Port UDP 1514 out (Local Subnet Only: Right-click rule → Scope → Add Local IP)

# 4. Items to Download

## a. WINDOWS UPDATES!!!

- b. Sysinternals Suite | http://bit.ly/GiveSys
- c. Nmap | http://bit.ly/GivePorts
- d. Wireshark | http://bit.ly/GiveShark
- e. Nxlog | https://bit.ly/GiveLog
- f. RSAT Tools | "Get-WindowsCapability -Name RSAT\* -Online | Add-WindowsCapability -Online"

### **5.** Sysinternals Suite

Autoruns: AutoRuns

- GatherNetworkInfo.vbs is OKAY (part of Autoruns)
- Check last modified date of files in System32 (very recent times = bad file)
- Colors:
  - Pink: No publisher information was found
  - Green: New item
  - Yellow: Startup entry is there but the file/job is not

Portmon: Monitor Port Activity

Process Explorer: View Running Processes

- Add the following columns: Autostart location, Users
- Options: Verify file signatures, replace task manager

Rootkit Revealer: Check for Rootkit(s) TCPView: View TCP/UDP Endpoints

## **Boot Processes -**

- 1. Enter System Configuration: msconfig.exe
- 2. Services Tab: Hide all Microsoft services; Disable unnecessary features
- 3. Startup Tab: Disable non-critical services
- 1. Search for "Turn Windows Features On or Off".
- 2. Uncheck:
  - a. Print and Document Services
  - b. SMB 1.0/CIFS File Sharing Support
  - c. Telnet Server & Client
  - d. XPS Services

Block Future PSEXEC Connections
C:\> reg add HKLM\Software\Microsoft\Windows\CurrentVersion\Policies\System /v
LocalAccountTokenFilterPolicy /t REG\_DWORD /d 0